


| | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|---|
| +5 | A2 | A4 | E0 | E2 | C0 | C2 | C4 | C6 | B0 | B2 | B4 | B6 | G |
| +5 | A1 | A3 | A5 | E1 | C1 | C3 | C5 | C7 | B1 | B3 | B5 | B7 | G |



16X2 Character LCD

LED B3

LED B4

LED B5

Pushbutton B0

Pushbutton B1

Piezo Buzzer

9 VDC

Keypad

D1 D2 D3 D4 D5 D6 D7
R1 R2 R3 R4 C1 C2 C3

Pushbutton Reset

USB

2 Pos Terminal Block

ICD

POT A0

www.ccsinfo.com

CCS Rapid-18