

Loranger item

NO	Part number	NO	Part number	NO	Part number
1	025025025J6617	18	03723-331-X218B	35	04333-101-6215
2	02901-032-6215	19	03727-091-X217	36	04334-081-6215
3	02950-041-6218A	20	060SQ049J6617 (replace 03940-491-6217)	37	04334-121-6215
4	030020015J6617	21	040SQ.02PJ6617	38	04334-121-6218C
5	03256-181-6215	22	04130-041-6215	39	04335081X215
6	03340-341-6215	23	499-P35-20(replace 04241-031-6218A)	40	04335-081-6215
7	03500-281-6211	24	04241-031-6218E	41	04335-081-6218A
8	03713 241 6218A	25	04241-031-X21B	42	04335-121-6215
9	03713 241 6218B	26	499-P38-20(replace 04243-041-6215)	43	04335-121-6218C
10	03714-171-6217	27	04245-051-6215	44	04335-281-6215
11	03714-171-6218J	28	04253-061-x217	45	04335-281-6218C
12	03714-251-6218B	29	04260-091-6218B	46	04336-081-X215
13	03714-321-6218A	30	04223-081-6215	47	04337-081-6218A
14	03714-651-6217(64PIN)	31	04262-081-X217	48	04337-141-6218E
15	03718-161-6215	32	042700916218A	49	04337-161-6215
16	03718-251-6218B	33	04328-041-6217	50	04338-081-6125--04338-081-6215
17	03722-091-6218B	34	04332-041-6217	51	04717-071-6217
				52	090SQ064B6617